



- M Manual (emergency) override.
Push and hold to operate.
- TP Test point connection (G $\frac{1}{8}$ ")

